



IMPORTANT! PLEASE KEEP FOR FUTURE REFERENCE, READ CAREFULLY

Comfort sun lounger


Dimensions when folded



Dimensions when up



Change of fabric



1. Instructions for use

- The lounger can be folded and set up only by adults.
- The lounger can only be placed on level surfaces.
- The lounger can be cleaned with a damp cloth.
- Avoid prolonged contact with rainwater.
- A wet lounger should be dried completely before storing.
- Store in a dry place.

2. It is not allowed

- to stand on any parts of the lounger;
- for children to use the lounger unattended;
- to move or lift the lounger with any people, animals or objects on it;
- to use the lounger when under the influence of alcohol;
- to place one's arms or legs between the side surfaces of the lounger's frame;
- to use the lounger less than 2.5 metres from any source of fire;
- to use a lounger with damage to any of its supporting parts or fabric.



Safety

All wooden elements have been rounded by sanding.




Kompaktość

The lounger is ready to use; light, only 4 kg. No assembly required.



Durability

Durable wooden frame made of beech wood. Maximum weight capacity: up to 110 kg.



Fabric

Changeable seat – quick and easy change of fabric, 23 colours available!